




## CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S

Onderdeel nommer:	CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S
Vervaardiger / Brand:	Schurter
Produk Beskrywing	SWITCH PUSHBUTTON SPST 100MA 42V
Inligtingsblaaie:	<a href="#">PDF CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S.pdf</a>
RoHS Status	 Loodvry / RoHS voldoen
Stuur Van	Hong Kong
Verskeping manier	DHL/Fedex/TNT/UPS/EMS

[VERSOEK VIR KWOTASIE](#)

Beeld kan voorstelling wees. Sien spesifikasies vir produkinligting.




### Spesifikasies van CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S

ONDERDEEL NOMMER	CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S
VERVAARDIGER	Schurter
BESKRYWING	SWITCH PUSHBUTTON SPST 100MA 42V
LEI VRYE STATUS / ROHS STATUS	Loodvry / RoHS voldoen
DATABLAD	<a href="#">PDF CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S.pdf</a>
VOLTAGE RATING - DC	60V
SPANNINGSWAARDE - AC	42V
TIPE	Capacitive, Illuminated
BEËINDIGINGSTYL	Wire Leads
SKAKEL FUNKSIE	Off-On
REEKS	CPS
PANEELUITSNYDIMENSIES	Circular - 19.10mm Dia
VERPAKKING	Bulk
WERKSTEMPERATUUR	-40°C ~ 60°C
MOUNTING TYPE	Panel Mount, Front
VOEGVOELIGHEIDSVLAK (MSL)	1 (Unlimited)
MEGANIESE LEWE	-
LEI VRYE STATUS / ROHS STATUS	Lead free / RoHS Compliant
INGRESS PROTECTION	IP67 - Dust Tight, Waterproof
VERLIGTINGSPANNING (NOMINALE)	5 ~ 28 VDC
VERLIGTING TIPE, KLEUR	LED, White/Cyan
KENMERKE	DOWN Symbol
ELEKTRIESE LEWE	-
GEDETAILLEERDE BESKRYWING	Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front
HUIDIGE BEOORDELING	100mA (AC/DC)
KLEUR - AKTUATOR / CAP	Silver
KRING	SPST
AKTUATOR TYPE	Round, Button, Flush

### Verwante Tags

Schurter CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S	CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S verspreider	CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S Verskaffer
CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S-prys	CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S-foto's	CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S-beeld
CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S PDF-datablad	CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S-datablad aflaai	CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S-datablad
CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S Voorraad	Koop CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S	Koop Schurter CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S
Schurter CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S	Schurter Verskaffer	Schurter verspreider
Schurter CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S	Schurter Inc. CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1068-S	

### Verwante Produkte

 <p><b>CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1074-S</b></p> <p>vervaardigers: Schurter          beskrywing: SWITCH PUSHBUTTON SPST 100MA 42V          Op voorraad: Out stock</p> <p><a href="#">RFQ</a></p>	 <p><b>CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1073-S</b></p> <p>vervaardigers: Schurter          beskrywing: SWITCH PUSHBUTTON SPST 100MA 42V          Op voorraad: Out stock</p> <p><a href="#">RFQ</a></p>
 <p><b>CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1066-S</b></p> <p>vervaardigers: Schurter          beskrywing: SWITCH PUSHBUTTON SPST 100MA 42V          Op voorraad: Out stock</p> <p><a href="#">RFQ</a></p>	 <p><b>CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1069-S</b></p> <p>vervaardigers: Schurter          beskrywing: SWITCH PUSHBUTTON SPST 100MA 42V          Op voorraad: Out stock</p> <p><a href="#">RFQ</a></p>
 <p><b>CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1065-S</b></p> <p>vervaardigers: Schurter          beskrywing: SWITCH PUSHBUTTON SPST 100MA 42V          Op voorraad: Out stock</p> <p><a href="#">RFQ</a></p>	 <p><b>CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1071-S</b></p> <p>vervaardigers: Schurter          beskrywing: SWITCH PUSHBUTTON SPST 100MA 42V          Op voorraad: Out stock</p> <p><a href="#">RFQ</a></p>
 <p><b>CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1070-S</b></p> <p>vervaardigers: Schurter          beskrywing: SWITCH PUSHBUTTON SPST 100MA 42V          Op voorraad: Out stock</p> <p><a href="#">RFQ</a></p>	 <p><b>CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1067-S</b></p> <p>vervaardigers: Schurter          beskrywing: SWITCH PUSHBUTTON SPST 100MA 42V          Op voorraad: Out stock</p> <p><a href="#">RFQ</a></p>
 <p><b>CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1063-S</b></p> <p>vervaardigers: Schurter          beskrywing: SWITCH PUSHBUTTON SPST 100MA 42V          Op voorraad: Out stock</p> <p><a href="#">RFQ</a></p>	 <p><b>CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1062-S</b></p> <p>vervaardigers: Schurter          beskrywing: SWITCH PUSHBUTTON SPST 100MA 42V          Op voorraad: Out stock</p> <p><a href="#">RFQ</a></p>
 <p><b>CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1072-S</b></p> <p>vervaardigers: Schurter          beskrywing: SWITCH PUSHBUTTON SPST 100MA 42V          Op voorraad: Out stock</p> <p><a href="#">RFQ</a></p>	 <p><b>CPS19-LA00A10-SNCSNCF-RI0WCVAR-W1064-S</b></p> <p>vervaardigers: Schurter          beskrywing: SWITCH PUSHBUTTON SPST 100MA 42V          Op voorraad: Out stock</p> <p><a href="#">RFQ</a></p>